

### **Engineering Chemistry**

CYC 102

Dr. Sukriti

School Of Basic Sciences

Indian Institute of Information Technology, Una Himachal Pradesh



#### **Overview**

- Numerical based on Alkalinity
- Summary



## Numerical based on Alkalinity

1. 100 mL of a water sample required 20 mL of N/50 H2SO4 for neutralization to phenolphthalein endpoint. After this, methyl orange indicator was added to this and further acid required was again 20 mL. Calculate the alkalinity of water as CaCO3 in ppm.

#### **Solution:**

• Volume of N/50 H2SO4 required to neutralize 100 mL water to phenolphthalein end-point V1 = 20 mL.

$$P = \frac{V1 \times N \times 50,000 \ mg}{volume \ of \ water \ (V)} \ mg \ CaCO_3/L$$

Where, V1 is the volume in mL of the standard acid used

N is the normality of the standard acid used

50, 000 is a conversion factor to change the normality into units of mg CaCO3/L.



# Numerical based on Alkalinity...Contd.

Phenolphthalein alkalinity, 
$$P = \frac{20 \times 0.02 \times 50,000 \ mg}{100} \ mgCaCO_3/L$$
  
= 200 mg/L

Now 100 mL of water up to methyl orange end-point = 20 + 20 = 40 mL N/50 H2SO4

Total alkalinity, 
$$T = \frac{[20+20] \times 0.02 \times 50,000 \, mg}{100} \, \text{mgCaCO}_3/\text{L}$$

$$= 400 \, \text{mg/L}$$
Now,  $P = 200 \, \text{mg/L} = \frac{1}{2} \, \text{T} \left[ \frac{1}{2} \times 400 \right]$ , so the alkalinity is only due to  $CO_3^{2-}$ .

(a)  $CO_3^{2-} + H^+ \rightarrow HCO_3^- \cdot P$ 
(b)  $HCO_3^- + H^+ \rightarrow H_2O + CO_3/T$ 

(a) 
$$CO_3^{2-} + H^+ \rightarrow HCO_3^- \cdot P$$

(b) 
$$HCO_3^- + H^+ \rightarrow H_2O + CO_2]T$$

Hence, total alkalinity (due to  $CO_3^{2-}$  only), T, is 400 mg/L



# Numerical based on Alkalinity...Contd.

2. 50 mL of sample of water required 5 mL of N/50 H2SO4 using methyl orange as indicator but did not give any coloration with phenolphthalein. What type of alkalinity is present? Express the same in ppm.

#### Solution:

As the water sample does not give any coloration with phenolphthalein (P = 0), hence only  $(HCO_3)$  are present.

Now, 50 mL of water sample upto methyl orange end point = 5 mL of N/50 H2SO4  $50 mL \times Nm = 5 mL \times \frac{N}{50}$ Normality, Nm = 5 mL × N/50 × 1/50 = 1/500 N

$$50 mL \times Nm = 5 mL \times \frac{N}{50}$$



# Numerical based on Alkalinity...Contd.

Now, strength of alkalinity upto methyl orange end point (in terms of CaCO3 equivalents)

 $= (Nm \times 50)g/L$ 

 $M = 1/500 \times 50 \text{ g/L} \times 1000 \text{ gm/g}$ 

 $\overline{M} = 100 \text{ mg/L} = 100 \text{ ppm}$ 

Hence, alkalinity due to  $HCO_3^- = M \pm 100$  ppm

Total alkalinely only

PZM WS PZD MS OND



## Summary

- Phenolphthalein and total alkalinity can be estimated
- Hydroxide, carbonate, bicarbonate ions can be identified along with the concentration based on alkalinity.



# Thank You!